



SP-8001 | M109 155mm Self-Propelled Howitzer M109A2/A3/A4/A5 Parts ONLY!

See parts list below

Note some parts are used take out - untested
All parts are sold AS-IS.

End Use Certificate required for any purchase

Export approval determination required

Used Take off Howitzer Parts

Part Number/NSN	Description
1662	Bulb,Mini
24836	COOL HOSE
26244	COOLANT HOSE 1" (qty in ft)
28409	COOLANT HOSE 3/8" (qty in ft)
42027	Decal
46966	LOCK NUT
49193	END CAP
68261	BOLT
379640	CABLE
5228783	FUEL INJECTOR

5228783	FUEL INJECTOR
8323640	SPRING
12011776	CONNECTING LINK; ARM,ADAPTER A
065794742	HARDWARE
00608-8	BATTERY WASHERS
1015-00-066-7093	SIGHT, FRONT
1015-00-123-0188	GUIDE,POWER PACK
1025-00-042-5307	EXTRACTOR,CARTRIDGE
1025-00-179-5639C	SEAT SUPPORT, COMMAND
1025-00-495-6526	RING, RETAINING
1025-00-937-7562C	M27 PERISCOPE
1025-01-012-8271	RING, OBTURATOR (11578862)
1025-01-021-9790	HANDLE, RAMMER
1025-01-054-5781	Cover, gun muzzle
1025-01-055-2786	CURTAIN ASSEMBLY
1025-01-070-3235	FRAME,PROJECTILE
1025-01-071-0633	Mount, alignmnet device
1025-01-073-7273C	BRACKET ASSY
1025-01-129-0257C	BRACKET ASSY
1025-01-129-0259C	BRACKET ASSEMBLY
1025-01-202-0418	ARM,ADAPTER ASSEMBLY
1025-01-213-7914	PARTS KIT
1025-01-277-5766	FITTING,FLUID,FILTER
1025-01-278-1321	BODY ASSEMBLY
1025-01-292-0960	FIRING MECHANISM ASSEMBLY
1025-01-292-3803	HAMMER,FIRING,CANNON
1025-01-361-1349	PIN,FIRING
1030-00-730-7416	Rammer, loading, M13
1090-00-933-2235	PARTS KIT,SEAL REPLACEMENT,ART
1090-00-937-2034	PARTS KIT, SEAL REPLACEMENT
11-5895-1774-12SP	TM manual set
1240-00-066-7096	LEVEL, FIRE
1240-00-114-1089	BELLOWS, ASSY
1240-00-114-1091	COVER, LEVEL
1240-00-177-4094	SPRING, HELICAL
1240-00-344-4643	PERISCOPE,ARMORED VEHICLE, M27
1240-00-509-2743	Periscope, armored vehicle
1240-00-864-0348C	Mount
1240-00-871-5475C	LINKAGE ASSEMBLY
1240-00-882-5940	Eyeshield, optical instr
1240-00-898-4217	CRANK, HAND
1240-00-943-0420	TERMINAL BOARD
1240-01-178-9752	LAMP ASSEMBLY, TELESCOPE
1240-01-291-9347	LEVEL ASM
1290-00-191-3302	SHELL RECEPTACLE
1290-00-346-8182	PLATE, SPRING
1290-00-653-7993	COVER, AIMING POST
1290-00-653-7993	Cover, fire control ins

1290-00-692-1493	LEVEL, FIRE CONTROL INSTRUMENT
1290-01-082-7981	SEAT, ECCENT
1650-00-222-4525	CAP,VALVE
1650-00-554-7430	FILTER ELEMENT, FLUID
200-OD	velcro (roll)
201-OD	velcro (roll)
2510-00-008-8821	TORSION BAR, SUSPENSION
2510-00-008-8822	TORSION BAR, SUSPENSION
2510-00-081-1137C	SIDE RACK, VEHICLE BODY
2510-00-105-9305C	RETAINER, PERISCOPE
2510-00-136-7424	BRACKET,HULL DOOR
2510-00-436-2031	ROD,WELDMENT,REAR DOOR
2510-00-443-0134C	SLEEVE PERISCOPE
2510-00-702-8146	BRACKET TORSION BAR
2510-00-871-2886C	TORSION BAR,SUSPENSION
2510-00-945-0632	BRACE,FENDER
2510-00-948-9979	FENDER,VEHICULAR {LEFT}
2510-00-999-2643	SUPPORT,INTAKE GRILLE
2510-01-072-4470	SPRING, LEAF
2510-01-088-1686	torsion bar
2510-01-183-5619	TORSION BAR
2510-01-226-3456	PLUG ASSEMBLY, DRAIN
2520-00-089-4149	SPRING
2520-00-395-7722	BREATHER
2520-00-689-3402	BREATHER
2520-00-738-8662	SPIDER,UNIVERSAL JOINT,VEHICUL
2520-00-972-2648	hyd motor kit
2520-01-335-7353C	CAP TRUNION
2520-01-353-0607	PARTS KIT, STEERING AXLE
2530-00-204-4800	CYLINDER ASSY
2530-00-421-3845	PARTS KIT, HYD
2530-00-493-9058	BRAKE SHOE
2530-00-493-9058	Brake shoe
2530-00-799-0021	PADS
2530-00-799-0022	LINK,TRACK SHOE,CONNECTING
2530-00-799-0023	WEDGE,TRACK SHOE
2530-00-876-8549	PARTS KIT
2530-01-060-7229	Lining, friction
2530-01-251-9265	BOOT, DUST AND MOISTURE SEAL
2530-01-310-2237C	Wheel, solid rubber
2540-00-089-7270	BRACKET,DRIVERS SEAT
2540-00-135-6547	HANDLE,DOOR,VEHICULAR
2540-00-216-5722	ROD, NON EXPANSIVE
2540-00-244-1321	BOX,ACCESSORIES STOWAGE
2540-00-244-1321C	BOX ASSY
2540-00-319-5981	HEAD ASSEMBLY,PRESSURE
2540-00-560-2169	DRIVERS SEAT BOTTOM
2540-00-670-2459	BAG ASSEMBLY PAMPHLET

2540-00-807-2841	HANDLE,DOOR,VEHICULAR
2540-00-808-7782	HANDLE,DOOR,VEHICULAR
2540-00-837-8694C	BOX, ACCESSORIES
2540-00-930-2718	BELT, VEHICULAR
2540-00-930-8935	Parts kit, shock absorb
2540-00-948-0181	SEAL, SHOCK ABSORBER
2540-01-079-3087C	BOX ACCESSORIES
2540-01-079-4637	SWITCH ASM
2540-01-080-4095	HANDLE, DOOR
2540-01-213-0030	BACKREST
2540-01-287-3974C	TROOP SEAT
2590-00-010-3794C	THROTTLE LINKAGE
2590-00-083-0266	RELAY AND HOUSING ASSEMBLY
2590-00-127-2921C	ACCUMULATOR, HYDRAULIC
2590-00-226-1694	BRACKET AND PULLEY
2590-00-345-8027	LEVER, REMOTE CONTROL
2590-00-345-8028	LEVER,REMOTE CONTROL
2590-00-411-8323	SCREEN,BILGE PUMP
2590-00-823-5584	SOCKET BASE, SPADE
2590-00-823-5584	SOCKET BASE,SPADE
2590-00-874-4430	PAD,CUSHIONING
2590-00-874-4430	Pad, cushioning
2590-00-930-0417	CONTROL ASSEMBLY, PUSH-PULL
2590-00-930-0417C	CONTROL ASSY
2590-00-934-8280	CUSHIONING PAD
2590-00-934-8283	BUMPER, SPADE
2590-00-967-6272	PARTS KIT, BILGE PUM
2590-00-999-5331	PLUNGER SPADE
2590-01-071-8895	PARTS KIT
2590-01-076-9368	PAD,CUSHIONING
2590-01-076-9368	Pad, cushioning
2590-01-076-9377	WIRING HARNESS,BRANCHED
2590-01-083-5424C	CLAMP, AMMUNITION RACK
2590-01-084-6056	WIRING HARNESS,BRANCHED
2590-01-108-9121	PAD, CUSHION
2640-00-250-2474	VALVE, EXTENSION
2640-00-810-5861	VALVE CORE
2910-00-025-3493	FILTER,FLUID
2910-00-103-4550	PUMP, FUEL ELECT
2910-00-113-0785	RETAINER,SEAL,HEAT SHIELD
2910-00-113-0788C	STIFFENER, HEAT SHIELD
2910-00-423-0941	NOZZLE
2910-00-710-6054	PUMP,FUEL,ELECTRICAL
2910-00-782-1376	PUMP, FUEL,METERING AND DIST
2910-00-782-1376	PUMP,FUEL,METERING AND DISTRIB
2910-00-798-4056	Cap Filler Opening
2910-00-837-1580C	PLATE, FUEL PUMP HOUSING
2910-00-880-4261	FLANGE,HOSE,FUEL TANK

2910-00-880-4261C	FLANGE, HOSE, FUEL TANK
2910-00-884-1207	FILTER ASSEMBLY,FLUID
2910-00-930-9367	PUMP,FUEL,ELECTRICAL
2910-00-937-7435	PUMP, FUEL ELECTRICAL
2910-00-948-0521C	WASHER
2910-00-999-8584	SEAL, FUEL TANK
2910-01-127-6911	FUEL PUMP DRIVE FORK
2920-00-184-7515	SWITCH,SOLENOID,STARTER
2920-00-334-5185	CONNECTOR AND SUPPRESSOR ASSEM
2920-00-900-7993	REGULATOR
2920-01-192-1737	DELCO STARTERS
2920-01-215-8785	PARTS KIT
2930-00-445-8927	PAD,RADIATOR SURGE
2930-00-725-5272C	SURGE TANK RETAINER
2930-00-860-2342	FASTENER,NONMETALLIC
2940-00-071-2653	INDICATOR
2940-00-421-1601C	DUCT AIR CLEANER
2940-00-580-6283	Filter element, fluid
2940-00-876-2212	FILTER ELEMENT
2940-00-933-4433C	FILTER ELEMENT
2990-01-259-7702	PIPE, EXHAUST
2990-01-334-4324	Pipe, Exhaust
3010-00-475-1290	PROPELLER SHAFT WITH UNIVERSAL
3010-00-574-8436	INSERT,FLEXIBLE COUPLING
3020-00-141-1154	SPROCKET, WHEEL
3020-00-789-2204	SPROCKET WHEEL
3020-00-789-2204C	Sprocket Wheel
3040-00-125-8783	WORM SHAFT
3040-00-345-8029	BELL CRANK
3040-00-345-8030	BELL CRANK
3040-00-466-1957	WORM SHAFT
3040-00-508-0126	ACCUMULATOR,HYDRAULIC
3040-00-508-0126C	ACCUMULATOR, HYDRAULIC
3040-00-689-3401	CAP,LINEAR ACTUATING CYLINDER
3040-00-700-8255	GEARSHAFT
3040-00-839-0150	LEVER, MANUAL CONTROL
3040-01-373-2865	LEVER,REMOTE CONTROL
3110-00-100-5937	BEARING,ROLLER,TAPERED
3110-00-100-6160	BALL, BEARING
3110-00-188-2740	BALL, BEARING
3110-00-214-0902	BALL,BEARING
3110-00-214-0903	BALL BEARING
3110-00-585-9430	BEARING,BALL,ANNULA
3120-00-835-4650	BUSHING
3120-00-930-4560	Bushing
3120-00-938-8185	BUSHING,SLEEVE
3120-01-131-0153	BEARING PLAIN
4010-00-907-0662	WIRE ROPE ASSEMBLY,SINGLE LEG

4010-01-149-0702	WIRE ROPE ASSEMBLY, SINGLE
4030-00-780-9350	HOOK,CHAINS
4030-00-851-4918	SWAGING SLEEVE
4210-00-168-2463C	FIRE EXTINGUISHER BRACKET
4210-00-270-4512	EXTINGUISHER FIRE 5LBS
4210-00-572-6223	DUAL PULL ME
4240-00-289-7978	GAS FILTER
4240-00-368-6291	PARTICULATE FILTER
4320-00-248-2013	PARTS KIT,HYDRAULIC PUMP
4320-00-446-3040	PARTS KIT,HYDRAULIC PUMP
4320-00-792-2082	FUEL PUMP
4320-00-796-2191	SEAL ASSEMBLY,SHAFT,SPRING LOA
4320-01-149-4900C	BRACKET PUMP
4320-01-308-9171	SEAL ASSEMBLY, SHAFT, SPRING
4330-00-566-3816	FILTER ELEMENT,FLUID
4330-00-740-3159	FILTER, FLUID (8356162)
4330-01-278-4613	FLUID FILTER
4330-01-281-9404	FILTER ELEMENT,FLUID
4520-00-790-8417	IGNITER
4710-00-168-2379	TUBE ASSEMBLY,METAL
4710-00-455-1406	TUBE,BENT,METALLIC
4710-00-472-4434	TUBE,BENT,METALLIC
4710-00-898-5649	Tube, Metallic
4710-01-056-5460	TUBE ASSY
4710-01-057-0000	TUBE,BENT,METALLIC
4710-01-057-6688	TUBE ASSY
4710-01-072-4708	TUBE ASSY
4710-01-073-0957	TUBE ASSY
4710-01-074-5022	TUBE ASSY
4710-01-259-0275	TUBE ASSEMBLY METAL
4710-01-278-1221	TUBE,METALLIC
4720-00-050-2090	HOSE ASSY
4720-00-277-8982	HOSE ASSEMBLY, NON-METAL
4720-00-345-8046	HOSE ASSEMBLY NONMETALLIC
4720-00-345-8047	HOSE ASSEMBLY,NONMETALLIC
4720-00-430-4230	HOSE ASSEMBLY,NONMETALLIC
4720-00-454-9517	HOSE ASSY
4720-00-455-1061	HOSE ASSEMBLY, NONMETALLIC
4720-00-684-3568	HOSE ASSEMBLY, NONMETALLIC
4720-00-808-7903	HOSE,AIR DUCT
4720-00-808-7904	HOSE,AIR DUCT
4720-00-808-7905	HOSE,AIR DUCT
4720-00-916-1902	HOSE ASSEMBLY, NONMETALLIC
4720-00-916-1902	HOSE ASSEMBLY,NONMETALLIC
4720-00-973-1264C	HOSE AIR DUCT
4720-00-993-4213	HOSE, PREFORMED
4720-00-999-8589	HOSE ASSEMBLY,AIR DUCT
4720-01-063-3857	HOSE ASSEMBLY, NONMETALLIC

4720-01-072-3371	HOSE ASSEMBLY, NONMETALLIC
4720-01-075-5066	HOSE ASSEMBLY, NONMETALLIC
4720-01-077-7983	HOSE ASSY
4720-01-077-7983C	FUEL HOSE
4720-01-081-2764	HOSE ASSEMBLY, NONMETALLIC
4720-01-094-9027	HOSE, AIR DUCT
4720-01-433-8308	Hose, nonmetallic (3/4" hose (in feet))
4730-00-014-3343	ELBOW, PIPE TO TUBE
4730-00-050-4208	FITTING, LUBRICATION
4730-00-087-2895	ELBOW, TUBE TO BOSS
4730-00-136-3153	CAP, TUBE
4730-00-138-4004	TEE, PIPE TO TUBE
4730-00-183-7678	MANIFOLD, HYDRAULIC SYSTEM ACCE
4730-00-203-3689	Elbow, tube
4730-00-203-3831	NUT, TUBE COUPLING
4730-00-249-3935	ELBOW, PIPE
4730-00-254-6211	ELBOW, PIPE TO TUBE
4730-00-277-5555	ELBOW PIPE
4730-00-277-6372	LOCKNUT, TUBE FITTING
4730-00-277-9731	SLEEVE, CLINCH, TUBE FITTING
4730-00-289-0051	ELBOW, PIPE
4730-00-289-0155	ELBOW, PIPE TO TUBE
4730-00-375-6405	LOCKNUT, TUBE FITTING
4730-00-446-3278	STRAINER ELEMENT, SEDIMENT (FUE
4730-00-494-6580	TEE, PIPE
4730-00-541-4901	REDUCER, BOSS
4730-00-541-7500	ELBOW, PIPE TO TUBE
4730-00-745-7786	SCREEN
4730-00-800-3129	SLEEVE, CLINCH, TUBE FITTING
4730-00-810-4499	NUT, TUBE COUPLING
4730-00-893-6402	STRAINER ELEMENT, SEDIMENT
4730-00-908-6293	CLAMP, HOSE
4730-00-968-6129	PLUG, PIPE, MAGNETIC
4730-01-090-7737	FLANGE, PIPE
4730-01-090-7737	FLANGE, PIPE
4730-01-202-9036	ADAPTER, PIPE TO TUBE
4730-01-244-8434	CLAMP, HOSE
4730-01-300-4091	ELBOW
4730-01-331-6630	CLAMP, HOSE
4730-01-346-2597	Elbow, Pipe
4810-00-475-1281	PARTS KIT, SOLENOID VALVE
4810-00-974-7605	VALVE, SOLENOID
4810-01-285-3031	Valve, Ball
4820-00-119-3761	VALVE, BLEEDER, HYDRAULIC SYSTEM
4820-00-202-5939	VALVE, CHECK
4820-00-245-7699	VALVE, ANGLE
4820-00-332-0083	VALVE, SHUTTLE
4820-00-391-3782	SHUTOFF

4820-00-475-1280	VALVE,CHECK
4820-00-915-5709	CAP,VALVE
4820-00-930-4074	VALVE,SAFETY RELIEF
4820-01-056-5341	VALVE, SAFETY RELIEF
4820-01-078-2419	VALVE,CHECK
4820-01-078-2419C	VALVE,CHECK
4820-01-131-2341	VALVE SAFETY RELIEF
4920-20-002-3717	adapter assembly, interface device
4930-01-082-6483	ADAPTER
4933-00-860-5445	SIGHT, BORE BREECH
50A92	coat and hat hook
5305-00-042-0991	SCREW, ASSY
5305-00-050-1946	SOCKET SCREW
5305-00-068-0509	SCREW,CAP,HEXAGON HEAD
5305-00-068-0515	SCREW,CAP,HEXAGON HEAD
5305-00-225-9092	BOLT
5305-00-269-3239	SCREW,CAP,HEXAGON HEAD
5305-00-269-3242	BOLT
5305-00-269-3247	BOLT
5305-00-273-7463	SCREW, CAP
5305-00-286-1289	SCREW
5305-00-701-5057	SCREW,MACHINE
5305-00-709-8523	SCREW,CAP,HEXAGON HEAD
5305-00-719-5240	SCREW,CAP,HEXAGON HEAD
5305-00-719-5270	SCREW,CAP,HEXAGON HEAD
5305-00-724-7223	BOLT
5305-00-725-0196	ALLOY STEEL SET SCREW
5305-00-726-2550	SCREW,CAP,HEXAGON HEAD
5305-00-726-2556	BOLT
5305-00-912-5113	BOLT
5305-00-922-7994	SCREW,CAP,HEXAGON HEAD
5305-00-926-1826	SCREW,CAP,HEXAGON HEAD
5305-00-954-2728	SCREW, MACHINE
5305-00-954-3487	SCREW,MACHINE
5305-00-958-6517	SCREW, CAP
5305-00-958-8492	SCREW, CAP
5305-00-959-2739	SCREW, MACHINE
5305-00-983-6658	SCREW
5305-00-988-5308	SCREW, CAP, SOCKET
5305-01-126-1051	SCREW, MACHINE
5305-01-158-7820	SCREW, ASSY
5305-01-159-2780	SCREW, ASSY
5306-00-042-5841	BOLT
5306-00-051-4084	BOLT
5306-00-068-0513	BOLT,MACHINE
5306-00-175-4967	BOLT
5306-00-225-9088	BOLT, MACHINE
5306-00-225-9089	BOLT, MACHINE

5306-00-225-9095	BOLT
5306-00-226-4829	BOLT MACHINE
5306-00-285-1368	BOLTS
5306-00-419-9483	BOLT,EXTERNALLY RELIEVED
5306-00-419-9545	BOLT,RIBBED SHOULDER
5306-00-423-8807	BOLT, MACHINE
5306-00-816-2441	BOLT, SQUARE
5306-00-944-3590	BOLT,HOOK
5306-01-049-9127	Bolt, Hook
5306-01-129-0327	BOLT, MACHINE
5306-01-155-6108	BOLT, MACHINE
5306-01-181-5018	BOLT
5306-01-195-4681	BOLT
5306-01-197-1492	BOLTS
5306-01-254-7359	ROD, THREADED END
5306-01-281-0557	BOLT, SELF LOCKING
5306-01-292-5236C	U BOLT
5306-01-314-6742	BOLT, RIBBED SHOULDER
5307-00-135-6546	STUD,SHOULDERED
5307-01-115-8147	STUD LOCKED
5310-00-019-0670	WASHER,LOCK
5310-00-109-6743	WASHER
5310-00-176-6333	NUT,SELF-LOCKING,HEXAGON
5310-00-186-1032	WASHER,KEY
5310-00-186-1295	WASHER,FLAT
5310-00-209-0788	WASHER,LOCK
5310-00-209-0965	WASHER,LOCK
5310-00-241-6664	NUT
5310-00-261-7340	WASHER,LOCK
5310-00-273-7771	NUT
5310-00-274-9364	NUT,SELF-LOCKING,HEXAGON
5310-00-293-9624	WASHER,KEY
5310-00-350-7265	NUT,PLAIN,SLOTTED,HEXAGON
5310-00-457-9314	WASHER, SPRING TENSION
5310-00-488-3888	NUT, SELF LOCKING
5310-00-507-3623	NUT, PLAIN, ROUND
5310-00-518-5566	NUT
5310-00-531-9120	WASHER, FLAT
5310-00-559-0070	WASHER,LOCK
5310-00-582-5965	WASHER,LOCK
5310-00-761-6871	NUT, PLAIN
5310-00-768-0319	NUTS
5310-00-799-4910	WASHER, SPRING
5310-00-809-3079	WASHER,FLAT
5310-00-809-4058	WASHER,FLAT
5310-00-814-0672	NUTS
5310-00-821-6269	WASHER,LOCK
5310-00-823-8803	WASHER,FLAT

5310-00-834-8734	NUT,PLAIN,HEXAGON
5310-00-877-7527	WASHER,FLAT
5310-00-880-7746	NUT,PLAIN,HEXAGON
5310-00-917-9734	WASHER, KEY
5310-00-926-5885	LOCK WASHER
5310-00-934-9739	NUT,PLAIN,HEXAGON
5310-00-934-9747	NUT,PLAIN,HEXAGON
5310-00-935-9022	NUT,SELF-LOCKING,HEXAGON
5310-00-959-1488	NUT,SELF-LOCKING,HEXAGON
5310-01-019-6527	NUT, PLAIN, HEXAGON
5310-01-052-2241	NUT-SELF LOCK
5310-01-099-0397	NUT
5310-01-102-2711	NUT
5310-01-150-4003	NUT, SELF LOCKING
5310-01-164-1642	FLAT WASHER
5310-01-176-0839	WASHER, FLAT
5310-01-196-5587	WASHER, FLAT
5310-01-253-8949	Washer, flat (or lock?) (5592926)
5310-01-267-3043	NUT
5310-01-302-9472	FLAT WASHER
5310-01-407-9566	WASHER
5315-00-140-1938	PIN
5315-00-187-3216	PIN, TAPPERED PLAIN
5315-00-187-3271	PIN,TAPERED,PLAIN
5315-00-198-6132	PIN, TAPERED
5315-00-271-4251	KEY
5315-00-432-0776	PIN, QUICK RELEASE
5315-00-439-8089	PIN, QUICK RELEASE
5315-00-495-6522	PIN,GROOVED,HEADED
5315-00-495-6522C	PIN
5315-00-631-1320	PIN
5315-00-740-4619	PIN,GROOVED,HEADED
5315-00-740-9379	PIN GROOVED HEADLESS
5315-00-741-8971	PIN, RETAINING
5315-00-775-3911	PIN,LOCK
5315-00-809-1442	ALLOY STEEL DOWEL PIN
5315-00-815-9366	PIN, STRAIGHT
5315-00-839-2326	PIN,COTTER
5315-00-842-3044	PIN,COTTER
5315-00-844-5830	PIN, SPRING
5315-00-844-5834	PIN, SPRING
5315-00-852-5694	PIN,STRAIGHT,HEADLESS
5315-00-864-0353	PIN,TAPERED,PLAIN
5315-00-930-4369	PIN,STRAIGHT,HEADED
5315-00-937-0965	PIN, QUICK RELEASE
5315-00-994-5793	PIN QUICK RELEASE
5315-01-212-6691	PIN,QUICK RELEASE
5315-01-334-3815C	PIN, STRAIGHT, HEADLESS

5315-01-334-4259	PIN,SHOULDER,HEADLESS
5320-00-011-2618	RIVET,SOLID
5320-00-117-6853	RIVET,SOLID
5320-01-333-9955	RIVET
5325-00-290-3820	STUD ASSY TURNLOCK
5325-00-449-2797	EYELET, TURNLOCK
5325-00-495-6526	RING,RETAINING
5325-00-582-3839	EYELET,TURNLOCK FASTENER
5325-00-637-2369	RECEPTACLE,TURNLOCK FASTENER
5325-00-739-7776	EYELET, METALLIC
5325-00-861-1467	RING,RETAINING
5325-00-861-1468	RING,RETAINING
5325-01-079-6709	GROMMET
5325-01-129-0277	GROMMET
5325-01-156-9497	Grommet, nonmetallic
5325-01-370-5562	Insert, panel fastener (rail) (82-2734242-1)
5330-00-034-4448	GASKET
5330-00-102-9927	SEAL,NONMETALLIC ROUND (11619289)
5330-00-111-2717	GASKET
5330-00-111-2734	GASKET
5330-00-117-2548	SEAL,NONMETALLIC ANGLE
5330-00-135-8988	SEAL,NONMETALLIC ANGLE
5330-00-154-8358	SEAL OIL
5330-00-179-0414	GASKET
5330-00-186-1380	WASHER, FLAT
5330-00-186-5856	GASKET
5330-00-246-6380	SEAL,PLAIN ENCASED
5330-00-290-0317	SEAL
5330-00-291-2858	SEAL PLAIN
5330-00-332-4818	GASKET
5330-00-374-4873	SEAL RING,METAL
5330-00-375-1690	GASKET
5330-00-428-0155	SEAL,PLAIN ENCASED
5330-00-446-3194	GASKET
5330-00-453-9353	SEAL, NONMETALLIC STRIP
5330-00-551-3737	MANIFOLD SET
5330-00-576-9731	O-RING
5330-00-584-0265	O-RING
5330-00-728-9956	SEAL, NONMETALLIC ROUND
5330-00-733-8104	GASKET
5330-00-735-4262	GASKET
5330-00-735-4270	GASKET, CONTROL VALUE BODY
5330-00-735-4296	GASKET
5330-00-736-0281	SEAL,TRANSMISSION
5330-00-741-1429	Seal, Plain Encased
5330-00-741-3774	GASKET
5330-00-751-9002	GASKET {STEER VALUE BODY}
5330-00-796-2242	SEAL,NONMETALLIC STRIP

5330-00-796-2243	GASKET
5330-00-796-2254	SEAL, NONMETALLIC ROUND SECTION
5330-00-809-1477	GASKET
5330-00-809-1481	GASKET
5330-00-821-2282	SEAL
5330-00-833-0870	VALVE COVER GASKET
5330-00-845-4368	GASKET
5330-00-846-9841	Gasket
5330-00-861-1476	RETAINER, PACKING
5330-00-873-5386	SEAL, NONMETALLIC SPECIAL
5330-00-874-6735	SEAL, NONMETALLIC SPECIAL SHAPE
5330-00-885-8465	SEAL, NONMETALLIC SPECIAL
5330-00-886-1188	SEAL, NONMETALLIC SPECIAL
5330-00-888-3792	GASKET
5330-00-899-5220	SEAL, NONMETALLIC ROUND SECTION
5330-00-899-5220C	SEAL, NONMETALLIC
5330-00-915-4511	GASKET
5330-00-930-5155	SEAL, HEAT SHIELD
5330-00-930-5156	SEAL, HEAT SHIELD
5330-00-936-8295C	SEAL
5330-00-961-9801	SEAL, PLAIN ENCASED
5330-00-967-3348	SEAL, HULL REAR DOOR
5330-00-968-3703	GASKET
5330-00-990-9144	GASKET
5330-00-998-9395	WATER BOILER
5330-00-999-8585	SEAL, NONMETALLIC SPECIAL
5330-01-064-3384	Packing
5330-01-065-9766	SEAL, NONMETALLIC STRIP
5330-01-078-7186	GASKET
5330-01-079-9598	SEAL, NONMETALLIC ROUND SEC
5330-01-082-1818	SEAL
5330-01-091-1268	RETAINER, PACKING
5330-01-098-2166	SEAL, NONMETALLIC SPECIAL SHAPE
5330-01-098-2322	RUBBER STRIP
5330-01-114-9226	O-RING
5330-01-130-3460	SEAL, PLAIN ENCASED
5330-01-157-3773	Seal
5330-01-176-7535	WIRE ROPE ASSEMBLY, SINGLE
5330-01-254-9804	SEAL, NONMETALLIC CHANNEL
5330-01-292-5375	SEAL PLAIN
5330-01-293-5336	SEAL, PLAIN
5330-01-293-5337	SEAL, PLAIN
5330-01-293-5338	SEAL, PLAIN
5330-01-308-9171C	SEAL ASSEMBLY, SHAFT
5330-01-345-7010	SEAL, NONMETALLIC SPECIAL SHAPE
5330-01-352-7768	DRAIN PLUG GASKET
5330-01-374-8921	GASKET
5330-01-374-8943	GASKET, RELAY VALVE

5330-01-375-2163	GASKET
5330-01-383-3753	GASKET
5330-01-387-2758	GASKET
5330-01-390-5248	GASKET
5330-01-453-1007	GASKET
5331-00-248-3843	O-RING
5331-00-250-0221	O-RING
5331-00-251-9376	O-RING
5331-00-285-9842	O-RING
5331-00-291-3275	O-RING
5331-00-297-5337	O-RING
5331-00-297-5337	O-RING
5331-00-579-3158	O-RING
5331-00-582-2133	O-RING
5331-00-599-2180	O-RING
5331-00-618-1920	O-RING
5331-00-647-0899	O-RING
5331-00-691-0145	O-RING
5331-00-802-1360	PACKING PREFORMED
5331-00-803-7208	O-RING
5331-00-804-5695	O-RING
5331-00-805-2966	O-RING (BUSHING, NONMETALLIC)
5331-00-807-8993	O-RING
5331-00-833-7491	O-RING
5331-00-844-2447	O-RING
5331-00-875-8288	O-RING
5331-00-882-5029	O-RING
5331-01-160-4329	O-RING
5331-01-160-4329	O-RING
5331-01-244-3527	O-Ring
5340-00-010-3797	COVER,ACCESS
5340-00-010-3797C	COVER, ACCESS
5340-00-020-3195	CLAMP,LOOP
5340-00-044-1890C	STRAP
5340-00-065-0753	PAD, CUSHIONING
5340-00-088-1255	CLAMP, LOOP
5340-00-102-3670	PAD, CUSHIONING
5340-00-103-5799	PAD, CUSHIONING
5340-00-133-9627	BRACKET,ANGLE
5340-00-133-9671	Bracket, Mounting
5340-00-135-4487	HOOK,SUPPORT
5340-00-178-1294	SHIM
5340-00-339-3768	STRAP WEBBING
5340-00-464-4792	STRAP,RETAINING
5340-00-475-1256	BRACKET,MOUNTING
5340-00-477-3755C	STRAP
5340-00-477-3756C	STRAP
5340-00-477-3760C	STRAP

5340-00-488-1071	SEAL, HEAT SHIELD
5340-00-543-3173	STRAP,WEBBING
5340-00-543-3742	STRAP
5340-00-740-4620	CLEVIS,ROD END
5340-00-807-2861	Pad, cushioning
5340-00-833-0342	CLIP, SPRING
5340-00-835-9815	SEAL ANTIPIRFERAGE
5340-00-851-4913	LEVER,LOCK-RELEASE
5340-00-878-6184	TORSION BAR, HINGE
5340-00-878-8955	TORSION BAR,HINGE
5340-00-918-6190	STRAP,WEBBING
5340-00-927-7289	PLUNGER,DETENT
5340-00-933-7464	STRAP,RETAINING
5340-00-944-8036	CAP,PROTECTIVE,DUST AND MOISTU
5340-00-984-5206	CATCH, CLAMP
5340-00-986-8674	COVER,ACCESS
5340-00-988-9958	MOUNT, RESIL
5340-00-989-1771	CLAMP, LOOP
5340-01-059-0114	CAP,PROTECTIVE,DUST AND MOISTU
5340-01-070-3186C	BRACKET
5340-01-070-3219	COVER,ACCESS
5340-01-072-9232	BRACKET,ANGLE
5340-01-079-4681C	MOUNTING BRACKET
5340-01-081-8281	SNAP HOOK
5340-01-096-2377	CLIPS
5340-01-116-2642C	DOOR ASSY, ACCESS
5340-01-214-3615	CLAMP LOOP
5340-01-217-3787	STRAP,RETAINING
5340-01-217-3788	STRAP,RETAINING
5340-01-222-4230	PLATE
5340-01-278-1255C	AIR PURIFIER BRACKET
5340-01-368-9993	CLIP,RETAINING
5340-01-375-6049	PLUNGER, QUICK RELEASE
5340-01-398-8661	STRAP,RETAINING
5340-01-423-2306	Strap, Webbing
5340-01-424-9481	Strap, Webbing
5340-01-461-1084	ground rod mount bracket
5342-00-408-9177	BRACKET, BRAKE CABLE
5342-00-966-7394	BELLOW
5342-00-993-8800	COUPLING, CLAMP, GROOVED
5342-00-993-8800C	COUPLING, CLAMP, GROOVED
5342-01-030-8085	MOUNT, RESILIENT, WEAPON SYS
5342-01-038-5708	CLAMP, COUPLING
5342-01-106-5488	COUPLING, CLAMP, GROOVED
5342-01-169-2882	Bracket assembly (flashing light mount)
5355-00-847-6260	KNOB
5355-00-850-9273	KNOB
5355-00-898-6791	KNOB ASSEMBLY

5355-00-995-1988	KNOB
5360-00-133-9615	SPRING, HELI
5360-00-179-1391	SPRING, HELI
5360-00-337-6970	SPRING, HELICAL, TORSION
5360-00-621-2427	TEST SET, INDICATOR
5360-00-820-3204	SPRING,HELICAL,COMPRESSION
5360-00-821-2452	SPRING,HELICAL,COMPRESSION
5360-00-824-0522	SPRING,FLAT
5360-00-854-6719	SPRING HELICAL
5360-00-861-1475	SPRING,HELICAL,COMPRESSION
5360-00-878-4173	SPRING,HELICAL,EXTENSION (SPAD
5360-00-878-8019	SPRING,HELICAL,COMPRESSION
5360-00-885-5730	SPRING,HELICAL,TORSION
5360-00-899-2160	SPRING,HELICAL,COMPRESSION
5360-00-914-8949	SPRING,HELICAL,COMPRESSION
5360-00-930-4253	SPRING
5360-00-930-4253	SPRING,HELICAL,TORSION
5360-00-986-8701	SPRING,HELICAL,EXTENSION
5360-01-026-1245	SPRING,HELICAL,COMPRESSION
5360-01-139-4695	SPRING
5360-01-282-9316	SPRING, HELICAL
5365-00-089-3608	SHIM SET
5365-00-090-5426	BUSHING,NONMETALLIC
5365-00-111-2739	BUSHING,NONMETALLIC
5365-00-178-1295	SHIM
5365-00-278-5325	PLUG
5365-00-445-8919	SPACER,HUB,TRACK SUSPENSION
5365-00-446-3269	BUSHING,NONMETALLIC
5365-00-453-5374	SPACER, RING
5365-00-462-2305	SPACER,SLEEVE
5365-00-566-3828	SHIM
5365-00-692-1492	RING, EXTERNAL
5365-00-737-6357	PLUG,MACHINE THREAD
5365-00-995-2006	SHIM
5365-01-112-3914	PLUG, MACHINE
5365-01-265-4839	SPACER,SLEEVE
5365-01-333-4725	SPACER,PROJECTILE
5365-01-355-5726	SPACER,PLATE
5365-01-424-5710	SPACER,PLATE
5855-01-235-5489	DRIVERS NIGHT VISION
5895-01-230-0266	GENERATOR PULSE
5895-01-567-9571	machine mount ethernet switch
5905-00-899-7645	REOSTAT
5905-00-933-6805	RESISTOR
5905-00-951-4527	RESISTOR, VARIABLE, WIRE
5925-00-247-2076	CIRCUIT BREAKER
5925-00-333-1584	CIRCUIT BREAKER
5930-00-345-5455	SWITCH,THERMOSTATIC

5930-00-577-8841	SWITCH, TOGGLE
5930-00-688-9881	SWITCH,THERMOSTATIC
5930-00-752-2766	SWITCH, TOGGLE
5930-00-772-9276	SWITCH,TOGGLE
5930-00-796-8845	SWITCH,LEVER
5930-00-944-1660	SWITCH PRESSURE
5930-00-991-1983	SWITCH,PUSH
5930-01-062-4903	SWITCH, TOGGLE
5930-01-062-4903	SWITCH,TOGGLE
5930-01-143-6762	Switch
5930-01-316-0975	SWITCH,TOGGLE
5930-01-491-9893	SWITCH ASSY
5935-00-062-7446	CONNECTOR,PLUG,ELECTRICAL
5935-00-167-7775	CONNECTOR, PLUG
5935-00-175-5966	COVER,ELECTRICAL CONNECTOR
5935-00-322-8959	ADAPTER, CONNECTOR
5935-00-322-8959	Adapter, Connector
5935-00-537-0167	elec connecotr shell
5935-00-572-9180	ELEC PLUG
5935-00-833-8561	SHELL,ELECTRICAL CONNECTOR
5935-00-900-6281	ADAPTER,CONNECTOR
5935-01-257-4037	connector, receptacle, electrical
5940-00-113-9821	TERMINAL, LUG
5940-00-549-6581	ADAPTER,BATTERY TERMINAL (+)
5940-00-738-6272	COVER,BATTERY TERMINAL
5945-00-435-1833	Relay, Electromagnetic
5945-00-636-8778	RELAY,ELECTROMAGNETIC
5945-00-6369-8778C	RELAY, ELECTROMAGNETIC
5945-00-690-2707	RELAY,ELECTROMAGNETIC
5945-01-163-5198	RELAY, ELECTROMAGNETIC
5945-01-192-8653	RELAY, ELECTRICAL
5965-01-348-8302	handset
5970-00-850-4337	INSULATOR
5977-00-432-7434	BRUSH, ELECTRICAL CONTACT
5977-00-432-7434	BRUSH,ELECTRICAL CONTACT
5977-00-432-7436	BRUSH,ELECTRICAL CONTACT
5977-00-433-4426	BRUSH,ELECTRICAL CONTACT
5977-00-455-6015	PARTS KIT
5977-00-741-4711	BRUSH, ELECT
5977-00-809-6907	BRUSH ELECTRIC
5977-00-809-6907	BRUSH ELECTRIC
5977-00-809-6908	BRUSH,ELECTRICAL CONTACT
5977-00-912-3899	HOLDER,ELECTRICAL CONTACT BRUS
5977-00-937-2544	ELECTRODE
5977-01-220-0128	Holder Assembly, Electrical
5980-01-285-6688	LIGHT EMITTING DIODE
5980-01-285-6689	LIGHT EMITTING DIODE
5980-01-289-5274	LIGHT EMITTING DIODE

5980-01-381-7900	LIGHT EMITTING DIODE
5985-00-115-7149	MAST
5995-00-050-5969	LEAD,ELECTRICAL
5995-00-104-8878	LEAD,ELECTRICAL
5995-00-823-2841	CABLE ASSY
5995-00-870-6234	LEAD,ELECTRICAL
5995-00-930-5162	WIRING HARNESS, BRANCH
5995-01-064-2951	CABLE ASSY
5995-01-093-4311	WIRING HARNESS
5995-01-133-1863	WIRING HARNESS,BRANCHED
5995-01-222-7942	WIRING HARNESS
5999-00-183-7687	CONTACT ASSY
5999-00-895-9191	CONTACT, ELE
6110-01-167-7252	REGULATOR
6110-01-278-6890C	NBC POWER BOX
6130-01-288-5237	RECTIFIER ASSEMBLY,METALLIC
6150-00-045-9901	LEAD ASSEMBLY,ELECTRICAL
6150-00-179-7999	LEAD,ELECTRICAL
6150-00-443-0099	LEAD AND CONDUIT ASSY.
6210-00-183-0511	LENS,LIGHT
6210-00-299-6509	LIGHT, INDICATOR
6210-00-553-0879	LIGHT, INDICATOR
6210-00-699-9457	LIGHT,INDICATOR
6210-00-715-3839	LIGHT,INDICATOR
6210-01-158-0392C	light, indicator
6220-00-337-7463C	DOME LIGHT
6220-00-796-2241	RETAINER,LENS
6220-00-932-4992	LIGHT, WARNING
6220-00-999-5285	GUARD,LAMP
6220-01-123-1353	LENS,LIGHT
6220-01-284-2709	LIGHT MARKER
6240-00-019-0877	BULB
6240-00-019-3093	LAMP, INCANDESCENT
6240-00-051-4843	LAMP, INCANDESCENT
6240-00-152-2982	lamp, fluorescent
6240-00-155-7836	LAMP, INCANDESCENT
6240-00-155-8714	LAMP, INCANDESCENT
6240-00-368-4972	LAMP,INCANDESCENT
6240-01-284-1925	LAMP, INCANDESCENT
6240-01-290-9346	LIGHT EMITTING DIODE BASED
6240-01-508-5347	LAMP ASSY
6620-00-810-3921	THERMOSTAT, FLOW CONT
6620-00-810-3926	THERMOSTAT, FLOW CONTROL
6620-00-993-5546	TRANSMITTER, PRESSURE
6620-01-181-1757	ELBOW
6625-00-335-9512	METER, ARBITR
6625-01-086-9580	METER, SPECIAL SCALE
6650-00-443-0161C	SLEEVE

6650-00-704-3549	PERISCOPE M17
6650-01-152-8516	RETICLE,OPT
6680-00-722-3730	ADAPTER, SPEED
6680-00-798-3056	ADAPTER, SPEEDOMETER-TACHO
6680-00-825-2076	TACHOMETER, MECHANICAL, FIXE
6680-00-825-2076	TACHOMETER,MECHANICAL,FIXED MO
6680-00-882-0965	SHAFT ASSEMBLY, FLEXIBLE
6680-00-933-3600	INDICATOR, FUEL
6680-00-973-1263	ADAPTER, SPEEDOMETER-TACHOM
6685-00-580-0935	GAUGE PRESSURE DIAL
6685-00-814-5271	TRANSMITTER, TEMPERATURE
6685-00-936-2138	INDICATOR, TEMPERATURE,ELECT
6695-00-893-6094	LIGHT,INSTRUMENT
7230-01-363-1145	curtain, blackout (top) (86-2734244-1)
7230-01-363-1147	curtain (86-2734245-2)
7690-01-168-6882	MARKER,IDENTIFICATION
7690-01-168-6883	MARKER, IDENTIFICATION
7690-01-168-6885	MARKER, INDENTIFICATION
8140-00-102-3671	PAD, CUSHIONING
88 TC	TC
9320-01-068-6531	RUBBER STRIP
9905-01-114-7589	PLATE ID
A-5123812	GOVERNER
A8927746	GASKET, rear crankshaft, detroit diesel
BR3780	SKF BEARING
G25170-1212	HYD HOSE FITTING
HW1125	GASKET
L1084	cable
M53060-6	CABLE
MS18628S	GASKET EXHAUST
MS35802-2	OIL FILTER
QRD150424	clothes line tightener charcoal cabin filter

M109 Howitzer NOS Parts List

Item ID	Item Description
10888029	Door, Assembly, Gunner
10888631	Cover, Driver
10909339	Adjuster Assembly, Commander
11593719	Cupola Assembly
12389716	Plate, Assembly
1025-00-110-9788	Support, Power Pack
1025-00-113-9615	Bracket Assembly
1025-00-115-0627	Cylinder Assy, Rammer
1025-00-179-5639	Seat Support, Commander
1025-00-186-5084	Control Box, Gunner
1025-00-475-1279	Power Pack Assembly

1025-00-493-9062	Cover ,Telescope Fan Assy
1025-00-937-4269	Support Assembly
1025-01-056-1247	Cover, Plate
1025-01-070-3235	Frame, Projectile
1025-01-071-0633	Mount, Alignment Device
1025-01-075-2346	Mechanism, Traversing
1025-01-076-7278	Projectile Stowage Rack
1025-01-137-7540	Door, Access, Left
1025-01-137-7541	Door, Access, Right
1025-01-137-7543	Bustle Door, Left
1025-01-137-7544	Bustle Door, Right
1025-01-150-5791	Shield, Gun
1025-01-213-2406	Rammer Assy, Rammer Support
1090-00-186-5078	Artillery Seal Replacement
1090-00-840-9552	Grip Assembly, Control
1090-00-937-2033	Parts Kit
1240-00-106-7754	Telescope, Panoramic M117A2
1240-00-344-4643	Periscope, Armored V M27
1240-00-509-2743	Periscope, Armored
1240-00-864-0348	Mount, Telescope M146
1240-00-871-5475	Linkage Assembly Support
1240-01-313-6842	Mount, Telescope M145A1
1240-01-317-9241	Telescope, Elbow M118A3
1290-00-896-2236	Quarant, Fire Control M15
1420-01-149-0717	Accumulator, Assembly, Primary
1420-01-149-0718	Accumulator, Piston, Secondary
2510-00-081-1137	Side Rack, Vehicle, Right
2510-00-081-1138	Side Rack, Vehicle, Left
2510-00-105-9305	Retainer, Periscope
2510-00-113-9609	Deflector, Exhaust Cover
2510-00-133-0984	Driver's Cover, Periscope
2510-00-133-9668	Door, Battery Access
2510-00-226-1690	Door, Hatch
2510-00-443-0134	Sleeve, Periscope
2510-00-948-9978	Fender, Vehicular, Right
2510-00-948-9979	Fender, Vehicular, Left
2510-01-083-5418	Panel, Indicator
2510-01-083-5419	Panel, Vehicular
2510-01-083-5433	Grille, Metal
2510-01-083-5437	Grille, Metal
2510-01-086-5411	Plate, Support, Door
2520-00-733-4744	Transmission
2530-00-133-9767	Wheel, Steering
2540-00-244-1321	Box, Accessories, Stowage
2540-00-446-0844	Seat Assembly, Commander
2540-00-475-1575	Armor, Mount Assembly
2540-00-706-8219	Hook, Tow
2540-00-837-8694	Box, Accessories, Stowage

2540-00-937-4538	Seat, Driver's
2540-01-073-4073	Stowage Box
2540-01-077-2003	Box, Accessories
2540-01-079-3087	Box, Accessories
2540-01-287-3974	Seat, Vehicular
2540-01-291-8210	Box, Accessories, LH
2590-00-083-0266	Relay and Housing
2590-00-127-2921	Hydraulic Accumulator
2590-00-226-2614	Mechanism, Turret Lock
2590-00-235-4369	Rack, Ammunition
2590-00-235-4372	Cradle, Ammunition Rack, Left
2590-00-235-4373	Cradle, Ammunition Rack, Right
2590-00-235-4374	Arm, Ammunition Rack, Left
2590-00-235-4375	Arm, Ammunition Rack, Right
2590-00-933-6259	Anchor Spade, Vehicle, Left
2590-00-933-6260	Anchor Spade, Vehicle, Right
2590-00-999-9839	Lock Assembly, Rack
2590-01-083-5424	Clamp, Ammunition Rack
2815-01-335-4579	Engine (TURBO) REBUILD
2815-01-610-1200	Engine (TURBO)
2815-01-610-1200	Engine (TURBO)
2910-00-837-1580	Plate, Fuel Pump
2920-00-900-7993	Engine Generator Regulator
2940-00-937-3681	Air Cleaner, Intake
3040-00-130-5354	Bracket, Eye, Rotating
3040-00-179-5502	Shaft, Shouldered
4140-00-782-1169	Fan, Personnel Air Duct
4240-00-807-6856	Heater, Air, Electric
4240-00-868-7906	Purifier, Air
4320-00-761-8901	Pump Unit
4320-01-441-5781	Pump Assy with Handle
4935-01-108-2968	Test Equipment
5306-00-944-3590	Bolt, Hook
5306-01-292-5236	U-Bolts
5330-00-968-3703	Gasket
5330-01-072-9518	Seal
5330-01-072-9518	Seal
5340-00-010-3797	Cover, Access
5340-01-056-5334	Latch, Rim
5340-01-158-3013	Cover, Access
5340-01-278-1255	Bracket, Angle
5340-01-359-8949	Cover, Access
5340-01-426-7932	Cover, Access
5342-00-420-4993	Door, Access
5342-00-992-8875	Bracket, Elevation
5342-01-083-5671	Door, Access
5342-01-083-5672	Door, Access
5945-00-636-8778	Relay, Electromagnet

5945-00-690-2707	Relay, Electromagnet
5945-01-291-0734	Relay, Electromagnet
5977-00-179-5163	Arm, Electrical Contact
5995-01-083-5730	Wiring Harness
5995-01-093-4313	Wiring Harness
6110-01-278-6890	Distribution Box
6130-01-288-5237	Rectifier
6160-00-411-8325	Tray, Battery
6160-00-932-5010	Retainer, Battery
6220-00-337-7463	Light, Dome
6650-00-443-0161	Sleeve, Periscope
6650-00-864-2933	Periscope, Armored V M42
6650-00-898-5771	Periscope, Case
6680-01-468-2049	Indicator, Liquid
7230-01-064-3374	Roller, Weather Cover
9320-01-068-6531	Rubber Strip
	Transmission Shift Control Assy
	Throttle Control Linage Assy